


\\chfs\Engineering\Design Manual\Standard Details for 2023 Revision\CAD\CAD details\EC-1603.dwg



MAINTENANCE:

1. INSPECT ALL MEASURES AT LEAST WEEKLY AND AFTER EACH RAINFALL OF 1.0 INCH OR GREATER.
2. CLEAN, AND PROPERLY MAINTAIN THE EXCAVATED BASIN AFTER EVERY STORM UNTIL THE CONTRIBUTING DRAINAGE AREA HAS BEEN PERMANENTLY STABILIZED.
3. REMOVE SEDIMENT WHEN THE VOLUME OF THE BASIN HAS BEEN REDUCED BY ONE-HALF.
4. SPREAD ALL EXCAVATED MATERIAL EVENLY OVER THE SURROUNDING LAND AREA OR STOCKPILE AND STABILIZE APPROPRIATELY.

NOTES:

1. CLEAR THE AREA OF ALL DEBRIS THAT MIGHT HINDER EXCAVATION AND DISPOSAL OF SPOIL.
2. GRADE THE APPROACH TO THE INLET UNIFORMLY.
3. PROTECT WEEP HOLES BY GRAVEL.
4. WHEN THE CONTRIBUTING DRAINAGE AREA HAS BEEN PERMANENTLY STABILIZED, SEAL WEEP HOLES, FILL THE BASIN WITH STABLE SOIL TO FINAL GRADING ELEVATIONS, COMPACT IT PROPERLY AND STABILIZE.

" NOT TO SCALE "



TOWN OF CHAPEL HILL
STANDARD DETAIL

REVISIONS

EXCAVATED DROP
INLET PROTECTION

DATE: 05/2024

EC-16.03